



MONTERING AV ROTTEFELLA FREERIDE SPACER

Rottefella Freeride Spacer monteres direkte på skien. Det er preget et merke i Spaceren. Dette merket skal korrespondere med skiens midtmerke. Bor hullene for frontbinding og hæl, fjern borespon fra hullene og bruk lim anbefalt av skiprodusenten ved montering. Monter skruene [8 stk.].

Rottefella Freeride Spacer gir økt trykk på kanten av skien. Spaceren hever bindingen 10mm og gir bedre kontroll på hard underlag og ved kjøring i bratt terreng.

MOUNTING THE ROTTEFELLA FREERIDE SPACER

Rottefella Freeride Spacer should be mounted directly on the ski. There is an imprint on the Spacer. This imprint should correspond with the ski's center mark. Drill holes for the front binding and heel, remove any debris from the holes, and use glue recommended by the ski manufacturer during mounting. Install the screws [8 pieces].

Rottefella Freeride Spacer provides increased pressure on the ski's edge. The spacer raises the binding by 10 mm and gives better control on hard surfaces and when skiing in steep terrain.

