





Rottefella Sport Binding Screw



Rottefella Sport
Binding Screw




Max=3N/m




Ø 3,6 x 15,5

6,3 x 19

- 1 Drill holes in the ski by using Rottefella Roller ski Jigg set to correct shoe size and balance point. Use the screws included to secure the heel plate before sliding the house into place, matching shoe size.



- 2 Secure binding with the included screws. Tighten carefully.



- 3 Slide the flex unit until it clicks in place.

