



XCELERATOR PROCLASSIC AND PROSKATE WITH QUICKLOCK



For roller ski: Use Rottefella Rollerski binding.

Versions:


Xcelerator Pro Classic
Xcelerator Pro Skate

Compatible Mounting plates:

Rottefella NIS 1.0 Mounting plate
Rottefella NIS 3.0 Mounting plate
Rottefella Mounting plate


1

Slide the binding onto the NIS plate from the top until it stops [1]. Push the binding backwards to "0" neutral position by lifting the rear of the QuickLock. Slide the heel onto the NIS plate from rear [2]. Push forwards to match shoe size by lifting the rear of the heel.



2

Move binding **forward**: Lift the front of the QuickLock and push forward to preferred position.




For better grip in classic skiing.



For more control in skate skiing.

3

Move binding **backwards**: Lift the rear of the QuickLock and push backwards to preferred position.



For better glide in classic skiing.



For better balance when skate skiing.