


# ROTTEFELLA®

## Xcelerator QuickLock bindings

[www.rottefella/quicklock](http://www.rottefella/quicklock)



**For Roller ski: Use Xcelerator Roller ski binding with safety screws only in combination with Xcelerator Mounting Plate!**


### Versions:

Xcelerator Pro Classic  
Xcelerator Pro Skate


### Compatible Mountingplates:

Rottefella NIS 7 Click Plate  
Rottefella NIS 3 Click Plate  
Rottefella NIS 1 Click Plate  
and Xcelerator Mounting Plate

1 Slide the binding onto the NIS plate from the top until it stops (1). Push the binding backwards to "0" neutral position by lifting the rear of the QuickLock™. Slide the heel onto the NIS plate from rear (2). Push forwards to match shoe size by lifting the rear of the heel.



2 Move binding **forward**: Lift the front of the QuickLock and push forward to preferred position.




For better grip in classic skiing.



For more control in skate skiing.

3 Move binding **backwards**: Lift the rear of the QuickLock and push backwards to preferred position.



For better glide in classic skiing.



For more speed and power in the kick in skate skiing.